## Brookville Equipment Corporation Product Information Bulletin 65 (11-6-06) Brookville Diesel Powered Rubber Tired Units Compliance Upgrade of the Supplemental Braking System

## Purpose:

The supplemental braking system does not automatically reset upon machine shutdown after the system has been manually released with the handpump.

## Action:

Proper action must be taken to retrofit the braking system to fully meet the requirements set forth by Title 30 Code Part 75.1909(c). Determination by unit serial number will decide the components required to correct the unit. Kits including these components will be prepared by Brookville and made available to the customers in possession of the affected units. Customers operating the machines with the serial numbers listed should contact the service department at Brookville Equipment at 814-849-2000 for instructions and availability of the components required. Failure to comply with corrective action may result in citations and/or removal of the machine from service.

## **Units Affected:**

Brookville Serial Numbers: RT500, 8400, 8401, 8522, 8636, 8742, 8743, 8808, 9003, 9004, 9005, 9038, 9056, 9057, 9058, 9059, 9060, 9061, 9062, 9063, 9100, 9114, 9115, 9123, 9124, 9125, 9126